I. Stack bags as required. Joints between bags in successive rows and tiers shall be staggered.

Temporary 4" min. dia. PVC pipe at 4'-0" max. spacing. After filling cavity below footing remove pipe

2. Refer to General Plan for any

excavation requirements.
3. Place top bag flush with face of footing.

4. If on piles, place debonding material around piles with greater than 3'-0" exposure.

5. All bags shall be Ift. max. thick, 3 ft. max. wide, and 4 ft. max. length.

6. Remove debris before installation of

FHWA APPROVAL DATE:

C.5 Freedown DIRECTOR OFFICE OF STRUCTURES DATE: 11/6/96 REVISIONS SHA FHWA 8-5-08

APPROVAL

STATE OF MARYLAND DEPARTMENT OF TRANSPORTATION STATE HIGHWAY ADMINISTRATION OFFICE OF STRUCTURES

GROUT BAG SECTION CASE WHERE SCOUR AND UNDERMINING HAS OCCURRED AT ABUTMENT

STANDARD NO. BR-SR(0.09)-96-316

SHEET \perp OF $\frac{7}{}$